

Sun Key Map

This is the mapping used to create special SUN keyboard keys on a PC PS2 or PC USB multi-media keyboard with at least a 104 key keyboard). The Right Control key is used as the trigger key because there is no equivalent key on a sun keyboard so there are no mapping issues.

Sun Key	PS2 or USB keystrokes
STOP	RT CTRL + F1
AGAIN	RT CTRL + F2
PROPS	RT CTRL + F3
UNDO	RT CTRL + F4
FRONT	RT CTRL + F5
COPY	RT CTRL + F6
OPEN	RT CTRL + F7
PASTE	RT CTRL + F8
FIND	RT CTRL + F9
CUT	RT CTRL + F10
HELP	RT CTRL + F11
POWER	RT CTRL + F12

These keys map directly to SUN keys from PS2 or USB keys

Sun Key	PS2 or USB keys
Left Alt	Left Alt
Left Special	Left GUI
Right Special	Right GUI
Compose	App
Alt Graph	Right Alt

Other multi-media keys that are directly supported (if present on a PS2 keyboard).

Volume Up	
Volume Down	
Mute	
System Power	