

## F5U208 Windows XP Installation

1. After unzipping the files onto your hard drive, the path you will have to specify during installation will be C:\F5U208. If you chose to unzip the files onto a 3 ½ floppy disk, the installation path would be A:\
2. When you plug in the adapter, Windows will find a new device, **(if Windows does not find a new device, follow the uninstall instructions first)**.
3. Windows will ask, What do you want the wizard to do? Choose, Install from a list or specific location (advanced). Click next.
4. Choose the option, Include this location in the search: and type the path c:\F5U208 (or you can browse to the C:\ and locate the folder that you unzipped the files to) and then click Next.
5. You will see a warning stating that the Belkin USB VideoBus II, Video has not passed Windows Logo testing, **Continue Anyway**. And click on Finish.
6. Windows will then find the Belkin USB VideoBus II, Audio. Windows will ask, What do you want the wizard to do? Choose, Install from a list or specific location (advanced). Click next.
7. Choose the option, Include this location in the search: and type the path c:\F5U208 (or you can browse to the C:\ and locate the folder that you unzipped the files to) and then click Next.
8. You will see a warning stating that the Belkin USB VideoBus II, Audio has not passed Windows Logo testing, **Continue Anyway**. And click on Finish.
9. In order to check the installation, go to Start, and right click on My Computer and left click on properties. Click on the Hardware tab and then click on the Device Manager button. Click on the plus sign next to Imaging Devices. Under this heading you should see a Belkin USB VideoBus II, Video. This would be the video capture option that you would choose in your application. Click on the plus sign next to Sound, video and game controllers. Under this heading you should see a Belkin USB VideoBus II, Audio. This would be the sound capture option that you would choose in your application. If you do not see either of these or if there is an unknown or USB device with a question or exclamation mark, proceed to the un-installation instructions.

## Uninstall Instructions

**(The adapter must be plugged in.) Look for any Question or Exclamation marks in front of any of the selections, if you see one in front of Belkin or unknown USB devices, remove these selections by right clicking on them and choose Uninstall, otherwise continue to next step.**

1. Leave the adapter plugged into the computer and go to Start, and right click on My Computer and left click on Properties.
2. Click on the Hardware Tab and then click on the Device Manager button.
3. Click on the plus sign next to Imaging Devices. Under this heading you should see a Belkin USB

VideoBus II, Video.

4. Right click on the Belkin USB VideoBus II, Video and choose Uninstall.
5. Click on the plus sign next to Sound, video and game controllers. Under this heading you should see a Belkin USB VideoBus II, Audio.
6. Right click on Belkin USB VideoBus II, Audio and choose Uninstall.
7. Close Device Manager and System Properties and Unplug the adapter from the computer.
8. Go to Start, Run and type c:\windows\inf, if this fails you can try c:\winnt\inf and click ok.
9. Scroll through the list of files and locate the files that start with OEM.
10. Windows creates an OEM and an OEM.PNF file for every device that you install to your system. Try locating the highest number OEM, (for example oem6 and oem6.pnf). If oem6 was the highest number, double click on the oem6 and scroll to the bottom and locate any information about Belkin or Etek. If you find this information, close the file and delete this oem and the oem.pnf with the same number. You can check the oem right below this number just in case. Then reboot your computer. Un-installation is complete.