

Belkin® USB Sync Charger for iPAQ™ Pocket PC User Instructions:

Charging your iPAQ series handheld through a powered USB port:

- 1 Plug the Sync Charger's USB connector into an available USB port on a desktop or laptop computer.
- 2 Plug the other end of the Sync Charger into the autosync connector at the base of the handheld. Be sure that the word PUSH is facing up. The Sync Charger will snap into place when securely attached.
- 3 Charge times will vary, but a fully discharged iPAQ handheld should charge completely within 2.5 hours, if not operated during the charging cycle.
- 4 To remove the cable from the autosync connector, depress the PUSH release on the head of the cable and gently pull back until the connector is released.


Charging your iPAQ series handheld through a USB automobile cigarette lighter socket:

- 1 Plug the USB cigarette lighter adapter into the car's cigarette lighter socket.
- 2 Plug the Sync Charger's USB connector into the USB receptacle located in the tip of the adapter.
- 3 Plug the other end of the Sync Charger into the autosync connector at the base of the handheld. Be sure that the word "PUSH" is facing up. The connector will snap into place when securely attached.
- 4 Charge times will vary, but a fully discharged iPAQ handheld should charge completely within 2.5 hours, if not operated during the charging cycle.

Synchronizing your iPAQ series handheld:

Note: ActiveSync® Desktop Software from Compaq must be installed on the PC to enable the synchronization function. To support an ActiveSync connection using USB, your host PC must be running Windows® 98 or Windows 2000. Microsoft® does not support an ActiveSync USB connection under Windows 95 or Windows NT®.

- 1 With your iPAQ turned on, plug the Sync Charger's USB connector into an available USB port on a desktop or laptop computer.
- 2 Plug the other end of the Sync Charger into the AutoSync connector at the base of the handheld. Be sure that the word PUSH is facing up. The Sync Charger will snap into place when securely attached.
- 3 If ActiveSync doesn't start synchronizing, select Connection Settings from the ActiveSync File menu.
- 4 Click off the Allow USB Connection setting, and click OK.
- 5 Go back to Connection Settings. Click on Allow USB Connection and click OK. ActiveSync should begin to synchronize your iPAQ to your PC.



Belkin Components, Ltd.
Unit 13 • Gatelodge Close • Round Spinney
Northampton • NN3 8RX • United Kingdom
Tel: +44 (0) 1604678300
Fax: +44 (0) 1604678330

Belkin Components
501 West Walnut Street
Compton • CA • 90220 • USA
Tel: 310.898.1100
Fax: 310.898.1111

Belkin Components, Ltd.
7 Bowen Crescent • West Gosford
NSW 2250 • Australia
Tel: +61 (2) 4372 8600
Fax: +61 (2) 4325 4277

© 2001 Belkin Components. All rights reserved. All trade names are registered trademarks of respective manufacturers listed. **P73796**