



belkin.com

To download the firmware:

1. Open a web Browser
2. In the address bar type `http://192.168.2.1`
3. Click on **Firmware Update** in the left hand column under **Utilities**.
4. Enter you password if any and click **Submit**.
5. Click on **Check Firmware**, and click **Download**
6. A window will open that allows you to select the location where you want to save the firmware file. Select a location.
7. When you have selected the location, click "Save". Once the download is complete, click "Close"

Note: *You can name the file anything you want, or use the default name. Be sure to download the file in a place where you can locate it.*

To install the firmware

1. From the Firmware Update page, click **Browse** a dialogue box will open that allows you to select the location of the firmware update file.
2. Browse to the firmware file you downloaded. Select the file by double-clicking on the file name.
3. The Update Firmware box will now display the location and name of the firmware file you just selected. Click "**Update**".
4. You will be asked if you are sure you want to continue. Click "**OK**"
5. You will see one more message. The message tells you that the Router may not respond to commands for as long as one minute. This is normal. Do not turn off or reboot the Router during this time. Click "**OK**"
6. A 60-second countdown will appear on the screen. When the countdown reaches zero, the firmware will be complete. The Router home page should appear automatically. If not, type in the Router's address (default = 192.168.2.1) into the address bar or your browser.

The Firmware update is complete.