



F5U002 USB Printer Adapter for Windows Millennium Edition Installation

1. Insert the Belkin USB Parallel Printer CD into your CD ROM Drive.
2. **Make sure your printer is turned off.** Connect the Belkin Parallel Printer Adapter to the parallel port on your printer. Turn your printer on.
3. Connect the included USB cable to the Belkin Parallel Printer Adapter.
4. Connect the USB connector to a free USB port on your computer. A New Hardware Wizard will appear on the screen. Windows will detect a USB Device.
5. Select "Automatic search for a better driver (Recommended)". Click "Next"



6. Windows will search for and install software for the "Belkin USB Printer Device v1.1. Click "Finish" to complete the software installation.
7. On the desktop, Right-click on "My Computer" and select "Properties". In the System Properties window, select the "Device Manager" tab. Verify that the "Belkin Deluxe USB Printer" is listed in the Device Manager.




8. Follow the directions under "Configuring Your Printer" to finish setting up your Belkin USB Parallel Printer Adapter.

Configuring Your Printer

1. Click "Start" then "Settings" then "Printers" to open the Printer dialog box.

2. Right-click on the icon for your printer. A menu will appear. Click on "Properties" then select the "Details" tab.



3. Under the heading "Print to the following port" click on the down facing arrow and select "LPT10:(Belkin Deluxe USB-LPT Port)".
4. Click "Spool Settings" and select "Disable bi-directional printing support for this printer". If this option is already selected, or is not available, this means that Bi-Directional printing is already disabled. Click "OK"

Printer Setup is complete. Click on the "General" tab and Click "Print Test Page" to ensure your printer is working properly.

Uninstall Procedure


To uninstall the Belkin USB Parallel Printer Adapter from your system, use the following steps.

1. Click "Start" then "Settings" then "Control Panel".
2. Double-Click on "Add/Remove Programs".



3. In the list of devices, locate "Belkin USB Printer Device v1.1" and highlight it by clicking once.

4. Click on the “Add/Remove” key.



5. The “USB Printer Uninstallation” window will appear. Select “Belkin Deluxe USB Printer” and click “OK”

Uninstallation is now complete.