

BELKIN®



User Manual
SportCommand™ for iPod®

Introduction

Congratulations and thank you for purchasing Belkin's SportCommand. Ideal for use during outdoor sports, this flexible armband-remote uses a touch-sensitive ElekTex® design to keep your iPod functional, dry, and secure—even during strenuous activity. SportCommand uses wireless radio-frequency (RF) technology to work at a distance of up to 50 feet. Please review this User Manual carefully so that you can be sure to get the most from your SportCommand.

Package Includes

SportCommand Receiver for iPod
SportCommand Remote Transmitter
Battery (model CR2032)
Armband
Armband Extension
Carabiner Clip



Setup Instructions

STEP 1 - SportCommand Receiver Setup

Power on your iPod. Then, plug the SportCommand Receiver into the bottom of the iPod (Fig. 1). The Receiver powers on automatically. Once the unit is on, we recommend engaging the hold switch on the iPod to prevent accidental button presses.

Note: The SportCommand Receiver can be used whether or not you use an iPod case.




Fig. 1

STEP 2 - SportCommand Remote Setup

1. Turn your Remote with the buttons facing up. Using a coin or something similar, turn the battery door counterclockwise and gently remove from the Remote (Fig. 2).
2. Insert the battery with the (+) side facing up (Fig. 3) and gently screw the battery door back into place. There are graphics on the Remote that indicate when the battery door is in the locked position.
3. Now press any of the Remote's buttons for the SportCommand Remote and Receiver to pair up. The green light on the Remote will blink when the first button-press command from the Remote reaches the Receiver correctly.



Fig. 2



Fig. 3

Operating Instructions

Connect any pair of headphones or speakers to the iPod via the 3.5mm headphone port. Place the iPod and Receiver into your pocket or backpack, using a case for extra protection.

You can also keep your iPod stationary with a stereo or boom box and remotely control up to 50 feet. Simply connect a 3.5mm audio cable from the iPod to the line-in port on a stereo receiver or speakers.

Attach the Remote to the VELCRO® patch on the armband with the control panel facing up (Fig. 4). Place the armband around your arm. Use the included extension to improve your fit, if necessary (Fig. 5).

If you prefer to wear the remote on your belt, backpack, or attached to another object, use the included carabiner clip. Simply guide it through the loop on the back of the Remote (Fig. 6).

You can now use your SportCommand Remote to control the iPod device's play/pause, skip-forward, skip-backward, and volume up/down functions while your iPod stays protected at all times. We recommend engaging the hold switch on the iPod to avoid accidentally initiating the iPod controls.




Fig. 4



Fig. 5



Fig. 6

Operating Instructions

Automatic Sleep Mode

If there is no key press for 30 seconds, the Transmitter will automatically go into sleep mode. The Transmitter will wake up with the next key press but it will not transmit the signal to the Receiver. The Transmitter will function for the subsequent key press.

Note: Shuffle and repeat controls are not compatible with iPod 3G models (10GB, 15GB, 20GB, 30GB, 40GB). When used with the iPod with color display, SportCommand lets you scroll through your slideshows or presentations—wirelessly.

Water-Resistant Design

The SportCommand Remote features a water-resistant, hand-washable design. Water beads off the surface of the Remote and cannot damage its functionality. However, the Remote is not submergible. Avoid using it during water-submersion activities such as swimming, surfing, and bathing. The Remote can be cleaned by hand with a little soap and water.

LED Chart

Every time you push a button on the Remote, the green lights on the Remote will blink, indicating that the signal has been received correctly. Shield the Remote from direct sunlight to improve legibility of the LED.

The Remote's battery level is automatically checked after every button press. If the battery level is low, the Remote's red light blinks once on each button press. The low battery should be replaced soon. The SportCommand will continue to function normally until the battery is exhausted.

Troubleshooting

Remote is not powering on or acknowledging a button press.

Ensure that the Remote battery is inserted correctly, with the (+) facing up, and the battery door is turned and locked into position.

After connecting the Receiver and Remote, there is no sound.

- Select a song on the iPod and press "PLAY".
- Make sure the headphones are correctly plugged into the iPod.
- Make sure the iPod is powered on.
- Make sure the Receiver is securely attached to the bottom of the iPod.
- Repeat STEP 1 and STEP 2 of the setup section.

Specifications

Operating Range: Up to 50 ft.

Transmission Method: Radio frequency

Frequency: 433MHz

Remote Battery: CR2032 3V

Remote Dimensions: 3.9 (H) x 2.7 (W) x 0.5 (D) in.

Remote Weight (including battery): 0.8oz.

Receiver Dimensions: 3.93 (L) x 0.89 (W) x 0.4 (D) in.

Receiver Weight: 0.5oz.

Armband Length: 14 in.

Armband-Extension Length: 9.86 in.

Environmental Specifications

Operating Temperature: -10° C ~ 40° C

Storage Temperature: -10° C ~ 50° C

Information

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

DECLARATION OF CONFORMITY WITH FCC RULES FOR ELECTROMAGNETIC COMPATIBILITY

We, Belkin Corporation, of 501 West Walnut Street, Compton, CA 90220, declare under our sole responsibility that the product:

F8Z076

to which this declaration relates:

Has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ICES

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe Best conforme à la norme NMB-003 du Canada.



Warranty

Belkin Corporation Limited 3-Year Product Warranty

What this warranty covers.

Belkin Corporation warrants to the original purchaser of this Belkin product that the product shall be free of defects in design, assembly, material, or workmanship.

What the period of coverage is.

Belkin Corporation warrants the Belkin product for three years.

What will we do to correct problems?

Product Warranty.

Belkin will repair or replace, at its option, any defective product free of charge (except for shipping charges for the product).

What is not covered by this warranty?

All above warranties are null and void if the Belkin product is not provided to Belkin Corporation for inspection upon Belkin's request at the sole expense of the purchaser, or if Belkin Corporation determines that the Belkin product has been improperly installed, altered in any way, or tampered with. The Belkin Product Warranty does not protect against acts of God (other than lightning) such as flood, earthquake, war, vandalism, theft, normal-use wear and tear, erosion, depletion, obsolescence, abuse, damage due to low voltage disturbances (i.e. brownouts or sags), non-authorized program, or system equipment modification or alteration.

Warranty

How to get service.

To get service for your Belkin product you must take the following steps:

1. Contact Belkin Corporation at 501 W. Walnut St., Compton CA 90220, Attn: Customer Service, or call (800)-223-5546, within 15 days of the Occurrence. Be prepared to provide the following information:
 - a. The part number of the Belkin product.
 - b. Where you purchased the product.
 - c. When you purchased the product.
 - d. Copy of original receipt.
2. Your Belkin Customer Service Representative will then instruct you on how to forward your receipt and Belkin product and how to proceed with your claim.

Belkin Corporation reserves the right to review the damaged Belkin product. All costs of shipping the Belkin product to Belkin Corporation for inspection shall be borne solely by the purchaser. If Belkin determines, in its sole discretion, that it is impractical to ship the damaged equipment to Belkin Corporation, Belkin may designate, in its sole discretion, an equipment repair facility to inspect and estimate the cost to repair such equipment. The cost, if any, of shipping the equipment to and from such repair facility and of such estimate shall be borne solely by the purchaser. Damaged equipment must remain available for inspection until the claim is finalized. Whenever claims are settled, Belkin Corporation reserves the right to be subrogated under any existing insurance policies the purchaser may have.

Warranty

How state law relates to the warranty.

THIS WARRANTY CONTAINS THE SOLE WARRANTY OF BELKIN CORPORATION, THERE ARE NO OTHER WARRANTIES, EXPRESSED OR, EXCEPT AS REQUIRED BY LAW, IMPLIED, INCLUDING THE IMPLIED WARRANTY OR CONDITION OF QUALITY, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, AND SUCH IMPLIED WARRANTIES, IF ANY, ARE LIMITED IN DURATION TO THE TERM OF THIS WARRANTY.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

IN NO EVENT SHALL BELKIN CORPORATION BE LIABLE FOR INCIDENTAL, SPECIAL, DIRECT, INDIRECT, CONSEQUENTIAL OR MULTIPLE DAMAGES SUCH AS, BUT NOT LIMITED TO, LOST BUSINESS OR PROFITS ARISING OUT OF THE SALE OR USE OF ANY BELKIN PRODUCT, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

This warranty gives you specific legal rights, and you may also have other rights, which may vary from state to state. Some states do not allow the exclusion or limitation of incidental, consequential, or other damages, so the above limitations may not apply to you.

BELKIN®

www.belkin.com

Tech Support

US: 310-898-1100 ext. 2263

800-223-5546 ext. 2263

Europe: 00 800 223 55 460

Australia: 1800 235 546

New Zealand: 0800 235 546

Singapore: 800 616 1790

Belkin Corporation

501 West Walnut Street

Los Angeles, CA 90220, USA

310-898-1100

310-898-1111 fax

Belkin Ltd.

Express Business Park, Shipton Way

Rushden, NN10 6GL, United Kingdom

+44 (0) 1933 35 2000

+44 (0) 1933 31 2000 fax

Belkin B.V.

Boeing Avenue 333

1119 PH Schiphol-Rijk, The Netherlands

+31 (0) 20 654 7300

+31 (0) 20 654 7349 fax

Belkin Ltd.

4 Pioneer Avenue

Tuggerah Business Park

Tuggerah, NSW 2259, Australia

+61 (0) 2 4372 8600

+61 (0) 2 4372 8603 fax

© 2006 Belkin Corporation. All rights reserved.

All trade names are registered trademarks of respective manufacturers listed.
iPod is a trademark of Apple Computer, Inc., registered in the U.S. and other countries.